

ALESSI WATCHES

Please refer to the following website for the caliber code of your watch.

www.alessi-watches.com

ENGLISH

HOW TO SET THE DIGITAL WATCH AL25000 SERIES

FEATURES

- (1) Time display
Hour and minute, and seconds are displayed.
- (2) Calendar display
Month and date are displayed.
- (3) Perpetual calendar
The calendar automatically adjusts for odd and even months including February of leap years from 2011 to 2060.
- (4) Illuminating light (Electroluminescent [EL] light)
The light illuminates the display for easy viewing in the dark.


BUTTONS AND DISPLAY



TIME/CALENDAR SETTING


Button B: To select digits to be adjusted

Button C: To set the flashing digits



- (1) In the time display, press button "B" to show the seconds setting display. The seconds digits start flashing.
- (2) Press button "C" in accordance with a time signal to reset the seconds to "00". The display will return to the time.
** When the seconds count any number from "30" to "59" and button "C" is pressed, one minute is added.*
- (3) In the seconds setting display, press button "B" to show the hour setting display. The hour digits start flashing.
- (4) With each press of button "B", the selection of the digits to be adjusted (flashing) is made in the above order.
- (5) Press button "C" to set the flashing digits. One digit is advanced with each press of button "C". The digits move quickly if the button is kept pressed.
- (6) After the date setting is over, pressing button "B" will return the display to time.

HOW TO SHOW THE CALENDAR DISPLAY



In the time display, pressing button “C” will show the calendar display (month and date).

The display automatically returns to the time in 2 to 3 seconds.

ILLUMINATING LIGHT (EL LIGHT)

Pressing button “A” in any display will turn on the EL light.

It keeps illuminating the display for three seconds after the button is released.

REMARKS ON THE BATTERY

BATTERY LIFE

When a new battery is installed, and the EL backlight is turned on 5 times or less per day, this watch can operate for approximately 24 months. (Battery life depends on frequency and use of certain features)

MONITOR BATTERY

The battery in your watch may run down in less than the specified period after the date of purchase, as it is a monitor battery inserted at the factory to check the functions and performance of the watch.

BATTERY REPLACEMENT

- Be sure to have the battery replaced with a genuine battery at an ALESSI watch store.
- If the old battery is left in the watch for a long period of time, a malfunction may be caused due to battery leakage, etc. Have it replaced with a new one as soon as possible.
- Battery replacement is subject to billing even if it runs down within the guarantee period.

For the OLED/LCD(AL25000 SERIES) watch, if the display becomes dim or no display appears by pressing button "B" (for OLED), replace the battery with a new one. For battery replacement, contact the retailer from whom the watch was purchased, and specify "CR2025" (for OLED)/ "LR1130" (for LCD- AL25000 SERIES).