

HOW TO INTERCHANGE THE CASE AL4000 SERIES


This watch has two cases: a central case with the crown (A), and an outer case (B, C, D).

The central case can be removed easily by pressing with the thumbs against the crystal. To reattach, simply snap the center piece back into the outer case.


This system makes it possible to use the same central case for a wrist watch, pocket watch and pendant watch.



A



B



C



D