


HOW TO SET A THREE-HANDED WATCH WITH 24-HOUR HAND AND DATE FUNCTION VT99

DATE SETTING

- (1) Pull out the crown to position 2.
- (2) Turn the crown counterclockwise to set the date.
- (3) Push the crown back in to position 1.



24-HOUR HAND AND TIME SETTING

- (1) Pull out the crown to position 3.
- (2) Turn the crown clockwise to advance the hands until the 24-hour hand and minute hand are aligned at the 12 o'clock position. The hands may not be pointed precisely at the 12-hour mark when lined up with each other but this minor variation is acceptable.
- (3) Push the crown back in to position 2. Turn the crown clockwise to advance the hour hand to align it with the other hands at 12 o'clock position. At this point, check that the date changes. If it does not change, advance the hour hand clockwise another 12 hours. When the hour hand has been lined up, immediately pull out the crown to position 3 to stop the watch's movement. If the crown remains in position 1 or 2, the watch will continue to gain and make the minute hand move, resulting in a failure to set the correct time.

- (4) Pull out the crown to position 3, and turn it clockwise to advance the hour and minute hands to the current time. If the current time is 9:00 A.M., the 24-hour hand must be pointing to the number "9". If it is 9:00 P.M., the 24-hour hand must be pointing to "21". If they do not match they are 12 hours apart and you will have to advance the hands by 12 hours to correct the AM/PM indicator.

- (5) Push the crown back in to position 1.

This procedure will set the 24-hour hand to correspond with the current time. It is also possible to set the 24-hour hand to a different time zone for dual time display.

SETTING THE 24-HOUR HAND TO A DIFFERENT TIME ZONE

- (1) Pull out the crown to position 3.
- (2) Turn the crown clockwise to advance the hands until the 24-hour hand points to the current hour in the desired different time zone.
- (3) Turn the crown clockwise to advance the hands until the minute hand is aligned at 12:00.
- (4) Push the crown back in to position 2. Turn it clockwise to advance the hour hand to set the current hour of the local time zone.
- (5) Pull out the crown to position 3, and turn the crown clockwise to advance the hour and minute hands to the current time.
- (6) Push the crown back in to position 1.

The hour and minute hands should now indicate the current time in your local time zone and the 24-hour hand should be pointing to the 24-hour time in the different time zone.